



Toshiba FlashAir

Wireless file transfer

When transferring still images from the a VideoProbe to a PC, the following steps are required:

1. Insert the FlashAir SD card into a Waygate Technologies approved USB SD card reader.
 - For Mentor Visual IQ (only), navigate to the SETTINGS menu > CONNECTIVITY > Turn OFF Wi-Fi.
2. Insert the USB card reader into the VideoProbe USB port.
3. In the VideoProbe settings menu select the FlashAir SD card as the default still image and video save location.
4. Save still images or video files to the FlashAir SD card.
5. On your PC, select the wireless network named "flashair" using password 12345678. Please ensure that the VideoProbe is powered on with the FlashAir card connected.
6. On your PC browser, visit the website <http://flashair>.
7. You will now be able to open and view the still images that you saved to the FlashAir SD card on your PC.

When transferring still images or a video from the VideoProbe to a smart phone or tablet, the following steps are required:

1. Follow steps 1-4.
2. Download the FlashAir application from the App Store. Search > "Flashair".
3. From your phone or tablet (Apple or Android) Settings menu, select the wireless network named "flashair" using password 12345678.
4. Open the FlashAir app on a phone or tablet and begin viewing still images and saved videos.

